

ABS Airbag Packing/Folding Procedure – FREERIDE Model



1. Deflated airbag, release button is under orange tab



2. Fully Opened Deflated Airbag



3. Fold bottom edge towards top of bag



4. Bottom edge folded over



5. Fold over top edge



6. Start to 'concertina' fold from the outside edge



7. Concertina folding in process



8. Fully 'concertina' folded airbags



9. Fully packed Freeride backpack.
Please note the correct positioning of the black and red plastic bases with the release valves. The airbags should be folded to the correct full internal length of the backpack.